

Warning

DO NOT USE on wood or tile floors that are highly worn, unfinished or have a wax or oil finish. If you are not sure what type of wood or tile floors you have, look in the "FAQs" section for a quick way to test, or call your flooring manufacturer or retailer.

DO NOT place hands in cartridge housing. Sharp hazard.

DO NOT attempt to refill the solution cartridges. Doing so could damage the seal, cause leakage and can result in plastic pieces blocking the spray nozzle causing permanent damage to the WetJet device.

DO NOT use rechargeable (nickel-cadmium) batteries. Use only non-rechargeable AA sized alkaline batteries, because rechargeable batteries might explode under fault conditions.

DO NOT try to disassemble the WetJet cleaning device because any attempt to do so may severely damage the connections and permanently damage or destroy the device.

Swiffer WetJet may not fully remove all stains. For these stains, try your usual speical scrubbing method or contact the flooring manufacturer for specific instructions.

DO NOT dispose of WetJet cleaning pads in the toilet.

DO NOT mix other cleaners with Swiffer WetJet solutions because this could cancel out the effectiveness of one or both cleaners.

Keep out of reach of children and pets.

In case of contact with the eyes, flush thoroughly with water. If irritation persists, call a physician.

DO NOT USE Swiffer WetJet to clean up or absorb flammable or combustible materials.

WetJet System



Swiffer WetJet Cleaning Solution


- safely cleans vinyl, marble, laminate, tile and finished wood floors
- dissolves even tough greasy stains
- ready to use, no rinse, no mix



low profile head easily reaches into corners, under furniture and into other hard to reach places



battery powered spray for easy dosing without fuss or mess



ergonomically designed handle

battery compartment

Dirt and solution is trapped inside to help prevent redeposit

Swiffer WetJet Cleaning Pad pulls dirt and solution deep inside to help keep dirt in the pad and off your floor



Floor Information

Swiffer WetJet cleans the following types of floors:



Wood and
Laminate



Marble



Stone Tiles



Ceramic Tiles



Vinyl

Do not use on unfinished, oiled, or waxed wooden boards, on non-sealed tiles, and carpeted floors. In case you would have any doubt regarding the surface safety of the Swiffer WetJet solution or the type of finishing of your floor, spray a small amount of solution on a small, inconspicuous area of the floor. Once completely dry, if a small white circle appears, the floor probably has a wax or oil finish. You can remove the small white circle by re-applying a small amount of wax finish.

Tips For Best Results

- Leave a clean pad attached and a bottle inserted so WetJet is always ready to go.
 - Sweep or vacuum before using WetJet.
 - Spray 3-4 seconds per square meter. It is important that you spray the right amount of cleaning solution to get the best results.
 - Use Wood Cleaner on finished wood and laminate floors.
- Bottles can be interchanged without risk of leakage.



US/E-U/EE.UU. 1 800-742-9220

www.wetjet.com

Assembly Instructions


1.



The WetJet device comes in three pieces which easily snap together.

- line up the arrows on each segment and snap together to lock permanently into place.
- when the device is assembled you can remove the arrows and throw them away.

2.



Insert 4 non-rechargeable AA alkaline batteries.

- open the battery compartment and follow the diagram for the correct direction to insert them.
- close the battery compartment by pressing until you hear a click.

3.



Insert the cartridge of Swiffer WetJet Cleaning Solution.

- insert the cartridge by putting the red arrow printed on the cartridge label, against the device pole and pushing the cartridge into the cartridge housing.
- DO NOT remove or puncture cap on the solution cartridge.

4.



Attach the WetJet Cleaning Pad.

- place the pad on the floor with the printed side facing up and placing the device head on top of the pad. OR hold the head of the device in one hand and the pad in the other with the printed side facing the device head.
- press the pad and device head together.




US/E-U/EE.UU. 1 800-742-9220
www.wetjet.com


See solution label for specific usage instructions.


Whole Floor Cleaning

Sweep or vacuum your floor first

-  **1.** **Spray solution**
Spray solution by holding button down for 3-4 seconds. This will dispense enough solution to clean 1 square meter

3-4 sec

-  **2.** **Cleaning up!**
Use the WetJet as you would an ordinary mop to wet clean your floors - but without the hassle!

-  **3.** **See the shine!**
Leaving you with a clean floor, no rinsing, no water, less time!

Tough Spots and Stains

-  **1.** **Spray solution**
Spray solution directly onto spot or stain, covering it thoroughly

-  **2.** **Leave to act**
Allow cleaning solution to soak for a few minutes


-  **3.** **Cleaning up!**
Clean the area by applying gentle pressure with the WetJet and cleaning pad

Ready to Use

Leave a clean pad attached and a cartridge inserted in WetJet so you are always ready to quickly and easily clean up spots and stains



Changing cleaning pad
When the WetJet cleaning pad appears too dirty, remove it from bottom of device head and throw it away.



Replacing cartridge
When the WetJet solution is empty, remove it by pushing the purple release button on the cartridge housing and throw it away. You may change the cartridge at any time because the cartridges are specially designed not to leak.

Frequently Asked Questions

For additional information and answers to questions, please visit our website at www.wetjet.com

Where can I use Swiffer WetJet?

WetJet safely cleans the following types of hard floors: tile, vinyl, marble, laminate, linoleum and polyurethane finished wood. For additional information on other floor types, please visit www.wetjet.com

How do I know if my floor has a polyurethane, wax or oil finish?

Place a small drop of water on a small, inconspicuous portion of the floor. When it is completely dry, if a small white circle appears the floor probably has a wax or oil finish. Remove the small white circle by re-applying a small amount of wax finish and then buffing. On floors periodically cleaned with wax or shine enhancing products, the WetJet cleaning solutions may remove the wax or shine coatings on the floor.

How much flooring area can I clean with one pad?

Under recommended use, each pad should clean approximately 30 square meters, about 323 square feet, which is about the entire floor area of two large rooms.

How much flooring area can I clean with one cartridge of Swiffer WetJet Floor Cleaning Solution?

Under recommended use, each cartridge should clean approximately 100 square meters, about 1076 square feet, which is about the entire floor area of 8 rooms.

How long should the batteries last?

Under regular usage conditions, the batteries provided will last through at least 7 cartridges of solution. When necessary, insert 4 new AA alkaline batteries. Some brands of batteries last longer than others so you may experience a different battery life after using the batteries included.

How do I know when and how much to spray?

A 3-4 second spray dispenses enough solution to clean about one square meter or eleven square feet, of floor. If your floors are especially dirty or you are not getting your floors as clean as you would like, use additional solution.

Can I change the solution cartridge even if it is not empty?

You may switch to another type of Swiffer WetJet solution, even if the cartridge is not empty. The cartridge has a special self sealing cap to prevent leakage.

Can I use different types of cleaning solutions with Swiffer WetJet?

No. Specially formulated WetJet solutions contain the correct amount of cleaning ingredients to safely clean your floors without leaving a dulling residue or requiring you to rinse.

What should I do when I finish a cartridge?

Throw away, or recycle where recycling facilities exist, empty solution cartridges and replace with new WetJet Cleaning Solution refill cartridges.

Can I store the device with the cartridge attached?

Yes, this way Swiffer WetJet is always ready to use when you need it. Store extra refill cartridges upright until needed.

What should I do when I finish using a cleaning pad?

Throw away dirty pads (do not dispose of in toilet) and attach a new one to the device.

Should I vacuum or sweep before using Swiffer WetJet?

Yes, Always vacuum or sweep to remove dirt and dust particles before using Swiffer WetJet. The Swiffer Sweeper completes this task easily.

Will Swiffer WetJet remove all stains and spots from my floors?

Swiffer WetJet is quite effective on a wide range of stains. For best results, treat stains as soon as possible. Swiffer WetJet may not fully remove old or set in stains, so use your usual method of removal or contact the flooring manufacturer for more specific advice.

How quickly does the floor dry?

The Swiffer WetJet super absorbent cleaning pad absorbs the solution off your floor, so drying time is minimal, usually a few minutes.

Can I use other Swiffer products on the Swiffer WetJet?

No, but we do recommend that you use the Swiffer Sweeper and Dry Cloths to sweep your floor before using WetJet.



- Do not fit rechargeable (Nickel-Cadmium) batteries. Use only non-rechargeable AA sized alkaline batteries, because rechargeable batteries might explode under fault conditions
- AVOID ACCIDENTS. KEEP OUT OF REACH OF CHILDREN AND PETS.
- If eye contact occurs with cleaning solution, rinse with water
- Do not place hands in the cartridge housing, sharp hazard

Trouble shooting guide

Problem	Possible Cause	Solution
Floor has streaks or hazing	Large dirt or dust particles	Sweep or vacuum before using WetJet
	Not using enough solution	Hold the spray button for 3-4 seconds or use more solution than you usually use on the floor
	Wax or shine enhancing products leave a coating on the floor	Test WetJet in an inconspicuous area. WetJet solution is specially formulated not to leave a dulling residue but it may affect the wax or shine coatings on the floor
Implement won't spray	Cartridge is inserted incorrectly	Check that the cartridge is fully and securely inserted
	Pump is not primed	Push the button on the handle and hold for several seconds until device begins to spray
	The motor is not running	Check that batteries are properly inserted. Replace the batteries if the motor still does not run.
The pad does not stick to the device	The wrong side of the pad is attached to the device	Check to be sure that the printed side is attached to the device
	The pad is not securely attached.	Use firm but light pressure to secure the pad to the device
Tough stains or spots	Tough spots and stains may need soaking	Spray the area and allow the solution to sit for a few minutes
	Tough spots and stains are not removed by Swiffer WetJet	Use your usual stain and spot removal method or contact the flooring manufacturer for more specific instructions.
Device leaks	The cartridge is not properly inserted	Check to make sure the cartridge is firmly and fully inserted securely into the device
	The seal and cap on the cartridge are damaged	Insert a new cartridge

ONE YEAR LIMITED WARRANTY SWIFFER WETJET

Important: Please save your receipt! Evidence of original purchase may be required for warranty coverage. If you have any questions regarding use of this product, call us at 1 800 742-9220

We are committed to keeping you satisfied. Swiffer WetJet warrants, for one full year, to the original retail owner, that this Swiffer WetJet appliance will be free of defects that are due to faulty material or workmanship. If the appliance should be defective within the warranty period, we will, at our option, replace the defective part or product free of charge. If you do not register your Swiffer WetJet by mailing us the enclosed card, your rights to the protection and service under the terms and conditions of this warranty may be affected.

Swiffer WetJet's One Year Limited warranty does not cover cleaning pads, cleaning solution cartridges or batteries.

The Swiffer WetJet One Year Limited Warranty to the original user shall terminate and be of no further effect one year after the date of original retail sale. The warranty is invalid if the appliance is not used as outlined in the User's Guide, including, but not limited to:

- damaged, or not maintained as reasonable or necessary
- modified, altered or used as part of any configurations not endorsed by Swiffer
- used in conjunction with any refills or parts not manufactured or endorsed by Swiffer
- abused, misused or used of other than the intended purpose or used commercially
- used to cause incidental or consequential damage to personal property resulting from misuse or possible defects with this appliance

If, after following the instructions in the User's Guide, you are certain that the appliance is defective, call us immediately at 1 800 742-9220 for further instructions. Please be sure to have available a complete description of the problem, proof of purchase and your name, address and telephone number.

This warranty gives you specific rights and you may have other rights which vary from state to state or country to country.